


⑩幅広千倉座




⑪幅広京中台



⑫幅広五重座



⑬雲形五重座



⑭屋根付五重座



⑮春日回出



⑯五重座回出

	板丈(cm)	①京中台 総高(cm)	②千倉座 総高(cm)	③蓮華付春日 総高(cm)	④勝美 総高(cm)	⑤五重座 総高(cm)	⑥出高欄 総高(cm)	⑦上京型面粉 総高(cm)	⑧上京中ワラビ 総高(cm)	⑨二重呂門 総高(cm)	⑩上京型吹蓮華 総高(cm)	⑪葵角切 総高(cm)	⑫春日 総高(cm)	⑬⑭黒檀漆 総高(cm)	⑮みかげ塗 総高(cm)
3寸	9	15.3	16	15	15.3	16.5	16.5	15.6	17	15.3	17.8	15.5	15	17	
3.5寸	10.5	17	18	17	17.3	18.6	18.9	17.8	17	17.3	17.8	17.7	17	17	
4寸	12	19.3	20	19	19.2	20.7	20.8	20	19.2	19.5	20	19.7	19.3	19	16.5
4.5寸	13.5	21.4	22.5	21.2	21	23.2	23.5	22	21.4	21.4	22	21.5	21.3	21	18
5寸	15	23.6	24.5	23.3	23	25.5	25.7	24	23.5	23.2	24	23.4	23.4	23.3	19.7
5.5寸	16.5	26	27	25.5	25.6	27.5	27.8	26.2	26.3	25.3	26.2	26	25.4	25.4	
6寸	18	28	28.7	28	27.7	29.5	30.2	28.5	27.9	27.2	28.3	28.4	27.8		

	板丈(cm)	板巾(cm)	⑩幅広千倉座 総高(cm)	⑪幅広京中台 総高(cm)	⑫幅広五重座 総高(cm)
2.5寸巾5寸	15	7.5	24.2	23	
2.5寸巾6寸	18	7.5	28.5	27.8	29.2
3寸巾	21	9	32.7	32.4	34.2
3.5寸巾	22.5	10.5	34.5	34.2	37
4寸巾	24	12	38	37.3	40
5寸巾	27	15	43	42	45
6寸巾	30	18	48	47	50

	胴丈(cm)	⑬雲形五重座 総高(cm)	⑭屋根付五重座 総高(cm)
18	18	41	39
21	21	47	47
24	24	53	54
27	27	60	60
30	30	67	66

6寸 5.5寸 5寸 4.5寸 4寸 3.5寸 3寸

